



VistaVent®  
Panel fit and universal venting material



# VistaVent<sup>®</sup>

## Venting Material - Panel Fit



- Eliminates condensation
- Reduces utility bills through added attic ventilation
- Prevents moisture, pests and dust from entering the structure
- Fits any ridge cap
- Custom cut profiles to fit most panels
- One person installation
- Two beads industrial strength adhesive
- No fiber debris in packages
- No installation hardware required
- Flame spread passes criteria for HB classification, Appendix 1 of ASTM D635
- 40 year limited warranty



## Specifications

**Net Free Area:** Up to 23 sq. in of NFA per lineal ft. of ridge\*

**Roof Slope:** Fits 2:12 and up

**Adhesive:** 2 beads of industrial strength adhesive  
3 ft. sticks have paper backing

**Air Permeability:** >800 cubic feet per minute

**Tear Strength:** 3.5 ppi

**Tensile Strength:** 16 psi - elongation 175%

**Compressive Strength:** 1.8 psi at 75%

**Abrasion:** No damage

**Water Infiltration:** Passes 110mph wind driven rain test

Made with unique polyester fiber to deliver durable, long-lasting performance

\* Based on 1" nominal thickness. Effective net free area determined by panel profile.

## Packaging

**Panel Fit Rolls** - Most profiles available in 20', 50' and 100' packages

**3 - Ft. Sticks** - Carton Packed

### 3/4" Hi Rib

1" high x 3" wide x 3' long  
72 ft. per carton

### R Panel

1-1/2" high x 3" wide x 3' long  
48 ft. per carton

## Easy Installation



### Step 1:

Make sure panel is free of dust and debris. If not pre-cut, cut 2" slot at ridge. Measure and mark where the ridge cap will sit on the panel.



### Step 2:

Start from the end of the ridge, installing VistaVent venting material along the length of the ridge (both sides), making sure the bottom edge of the venting is 1/2"-1" up-slope from the edge of the ridge cap.



### Step 3:

When attaching consecutive ridge vents, butt fit the pieces together. Sealant can be used to seal the butt joint. Place ridge cap over ridge vent. Secure in place with fasteners; fasten through the metal roof rib locations, using an appropriate screw gun.

# VistaVent<sup>®</sup>

---

## Venting Material - Universal



- Eliminates condensation
- Reduces utility bills through added attic ventilation
- Prevents moisture, pests and dust from entering the structure
- Fits any ridge cap
- Available in three sizes
- One person installation
- Two beads industrial strength adhesive
- No fiber debris in packages
- No installation hardware required
- Flame spread passes criteria for HB classification, Appendix 1 of ASTM D635
- 40 year limited warranty



## Specifications

**Net Free Area:** Up to 23 sq. in of NFA per lineal ft. of ridge\*

**Adhesive:** 2 beads of industrial strength adhesive

**Air Permeability:** >760 cubic feet per minute

**Cold Cracking:** -55°C (-130°F)

**Tear Strength:** 3.5 ppi

**Tensile Strength:** 16 psi - elongation 175%

**Compressive Strength:** 1.8 psi at 75%

**Abrasion:** no damage

Made with unique polyester fiber to deliver durable, long-lasting performance

\* Based on 1" nominal thickness. Effective net free area determined by material size and panel configuration.

### Packaging (2 Rolls / Package)

**1" x 2" x 10':**

Fits rib heights up to 3/4"

**1" x 3" x 10':**

Fits rib heights up to 3/4"

**1-1/2" x 3" x 10':**

Fits rib heights up to 1-1/4"

## Easy Installation



### Step 1:

Make sure panel is free of dust and debris. If not pre-cut, cut 2" slot at ridge. Measure and mark where the ridge cap will sit on the panel.



### Step 2:

Start from the end of the ridge, rolling out VistaVent universal venting material along the length of the ridge (both sides), making sure the bottom edge of the venting is 1/2"-1" up-slope from the edge of the ridge cap.



### Step 3:

Apply ridge cap, compressing material between the ridge cap and major rib. Fasten at the major rib using an appropriate screw gun.

## Selection

VistaVent® panel fit rolls are available to match most major OEM profiles. Material numbers listed for existing profile/package options. Please contact SFS for details on profiles not shown.

### VistaVent® Panel Fit - Exposed Fastener Panel Profiles

Panel Description	100' Package 2 x 50' Rolls		50' Package 2 x 25' Rolls		3' Sticks		
	Material No.	Pallet Qty.	Material No.	Pallet Qty.	Material No.	Carton Qty.	Pallet Qty.
2.67 x 7/8" Corr	1549906	1400'					
3/4" Hi-Rib	1549907	1400'	1549921	1400'	1549948	72'	1728'
5V Panel	1549922	1400'	1549924	1400'			
ABC 7/8" Wide Rib	1549925	1400'					
ABC Regal Rib	1549926	1400'					
ABC Rugged Rib	1549927	1400'					
Agri Panel	1549931	1400'					
Ameri-Drain	1549932	1400'					
Delta Rib	1549933	1400'					
M / U Panel	1549936	1400'	1549937	1400'			
Mueller AP Panel			1549943	1400'			
Multi Rib	1549944	1400'					
Pro-Panel II	1549950	1400'	1549952	1400'			
R Panel	1549953	1400'	1549956	1400'	1549949	48'	1152'
SSR Panel 16"	1549957	700'					
Strong Panel	1549958	1400'	1560911	1400'			

### VistaVent® Panel Fit - Standing Seam Panel Profiles

Panel Description	100' Package (2 x 50' Rolls)		50' Package (2 x 25' Rolls)	
	Material No.	Pallet Qty.	Material No.	Pallet Qty.
1" x 5/16" x 12" Panel	1549902	1400'		
1" x 5/16" x 16" Panel	1549903	1400'	1549904	700'
ABC SL-16	1549928	1400'		
Metalogic 3000 12"			1549941	1400'
Metalogic 3000 16"	1549942	1400'		

### VistaVent® Universal

Size	20' Package (2 x 10' Rolls)	
	Material No.	Pallet Qty.
1" high x 2" wide	1549934	1800'
1" high x 3" wide	1549935	1260'
1-1/2" high x 3" wide	1551418	840'

#### Technical advice and sales service

SFS Group USA, Inc.  
Division Construction  
1045 Spring Street  
US-Wyomissing, PA 19610

800 234 4533  
T +1 610 376 5751  
F +1 610 376 8551  
us.construction@sfsintec.biz  
www.sfsintecusa.com

SFS intec - Canada  
40 Innovation Drive  
Dundas, ON L9H 7P3  
T +1 905 689 5401  
ca.info@sfsintec.biz  
www.sfsintec.ca

